

Lenovo IBM IdeaPad:

- G50
- L410, L412, L420, L510, L512, L520
- R60, R60i, R60e, R61, R61i, R61e, R400 (Type 7443)
- SL300, SL400, SL400C, SL410, SL500 (Type 2746), SL500C, SL510
- T60, T60p, T61, T61p, T400, T400s, T410, T410i, T410s, T410si, T420, T420s, T430, T430s, T500, T510, T510i, T520, T520i, T530
- W500 (Type 4062), W510
- X1, X60, X60 Tablet (X60t), X60s, X61, X61 Tablet (X61t), X61s, X100e, X120e, X121e, X130e, X200, X200 Tablet (X200t), X200s, X201 (3113WNE), X201 Tablet (X201t), X201i, X201s, X220, X220 Tablet (X220t), X220i, X220i Tablet (X220it), X230, X230 Tablet (X230t), X300, X301
- Z60, Z60M, Z60T, Z61, Z61t, Z61e, Z61m, Z61P

Lenovo 3000 Series:

- C100, C200, N100, N200 (Type 0769), V100, V200
- Lenovo IdeaPad Edge E120, E125, E135, E220s, E420, E425, E430, Edge 11", Edge 13" (E30, E31), Edge 14" (E40), Edge 15" (E50, NVM3TUK), Edge Twist
- Edge E320 (1298-3SG, 1298-5NG, 1298-7ZG, 1298-A8G)
- Edge E330 (3354-94G, 3354-4PG, 3354-AUG)
- Edge E420s (4401-5CG, 4401-7SG, S430, 3364-3EG, 3364-5JG, 3364-58G, 3364-56G)
- Edge E520 (1143-3MG, 1143-3NG, 1143-B4G, 1143-B3G, 1143-JYG, 1143-GVG)
- Edge E525 (3259-BQG, 3259-C2G, 3259-HJG, 3259-A3G, 3259-A4G)

- Edge E530 (3259-M3G, 3259-MAG, 3259-MCG, 3259-MDG, 3259-MEG, 6272-3HG, 6272-3GG, 6272-3AG, 6272-39G, 6272-38G 6272-4QG, 6272-4AG, 6272-49G, 6272-3QG, 6272-3PG, 6272-3NG, 6272-3EG, 6272-3DG, 6272-3CG, 6272-3BG 6272-34G, 6272-33G, 6272-32G)
- Edge E535 (3260-8KG, 3260-ELG, 3260-DWG)