

Batería HP

Compaq Presario:

CQ42-153TX

CQ42-151TX

CQ42-152TX

CQ42-154TX

CQ42-184TX

CQ42-179TX

CQ42-180TX

CQ42-181TX

CQ42-182TX

CQ42-191TX

CQ42-192TX

CQ42-193TX

CQ42-194TX

CQ62-105TX

CQ62-108TX

CQ42-106TU

CQ42-167TX

CQ62

CQ72 series

G62 Series

G62-100

G62-100EB

G62-103XX

G62-105SA

G62-106SA

G62-110SS

G62-120EL

G62-120ES

G62-120SL

G62-140EL

G62-140US

G62-144DX

G62t-100

CTO G62-130

G72-130

HP Pavilion:

dm4-1000 series

dm4-1001tu

dm4-1002tx

dm4-1008tx

dm4-1009tx

dm4-1010tx

dm4-1013tx

dm4-1014tx

dm4-1015tx

dm4-1060us

m4-1065dx

dm4t

HP Envy:

17 Notebook PC