

HP-90W/19.5V/4.62A/4,5*3

HP

Envy Series

15-J000 CTO, 15-J000EB, 15-J000ER, 15-J000SG, 15-J001ER, 15-J001SB, 15-J001SG, 15-J001TX, 15-J002EA, 15-J002ER, 15-J002LA, 15-J003EO, 15-J003LA, 15-J004AX, 15-J004TX, 15-J005EP, 15-J005SS, 15-J005TU, 15-J006AX, 15-J006CL, 15-J007AX, 15-J008AX, 15-J009SS, 15-J010US, 15-J011NR, 15-J012LA, 15-J013CL, 15-J016TX, 15-J019SO, 15-J022TX, 15-J023CL, 15-J024SA, 15-J025TX, 15-J026TX, 15-J027TX, 15-J028TX, 15-J030TX, 15-J030US, 15-J031NR, 15-J032NR, 15-J033TX, 15-J058CA, 15-J060EZ, 15-J063EI, 15-J066EZ, 15-J081EG, 15-J084CA, 15-J084NR, 15-J090EZ, 15Z-J000, 15Z-J000 CTO, 15Z-J100, 17-J000, 17-J001TX, 17-J005EO, 17-J008EO, 17-J010EL, 17-J010US, 17-J011NR, 17-J011SA, 17-J011SP, 17-J013CL, 17-J020US, 17-J021NR, 17-J023CL, 17-J027CL, 17-J029NR, 17-J030US, 17-J034CA, 17-J040NR, 17-J040US, 17-J041NR, 17-J043CL, 17-J044CA, 17-J050US, 17-J051EI, 17-J057OL, 17-J060US, 17-J070CA, 17-J070EZ, 17-J073CA, 17-J082EG, 17-J092NR, 17-J098EF, 17-J099NR, 17-J120US, 17-J130US, 17-J150NR, 17-J160NR, 17-J170CA,

Envy Quad Series

15T-J000, 15T-J100, 17T-J000,

Envy Select Series

15T-J000, 15T-J100, 17T-J000, 17T-J100,

Envy TouchSmart Series

15-J001AX, 15-J001TU, 15-J002AX, 15-J002TU, 15-J003AX, 15-J003CL, 15-J005AX, 15-J006TU, 15-J050US, 15-J052NR, 15-J053CL, 15-J053XX, 15-J063CL, 15-J067CL, 15-J073CA, 17-J000, 17-J010DX, 17-J023CL, 17-J030US, 17-J037CL, 17-J043CL, 17-J078CA, M7-J010DX, M7-J020DX, M7-J078CA,

Pavilion Series

14-E001TX, 14-E002TX, 14-E003TX, 14-E004TX, 14-E005TX, 14-E006TX, 14-E007TX, 14-E008TX, 14-E009TX, 14-E010TX, 14-E011TX, 14-E012TX, 14-E013TX, 14-E014TX, 14-E015TX, 14-E016LA, 14-E016TX, 14-E017TX, 14-E018LA, 14-E018TX, 14-E019TX, 14-E020TX, 14-E036TX, 14-E037TX, 14-E038TX, 14-E039TX, 14-E045TX, 14-E046TX, 14-E047TX, 14-N004AX, 14-N005AX, 14-N006AX, 14-N007AX, 15-E001TX, 15-E002AX, 15-E002TX, 15-E003AX, 15-E003TX, 15-E004AX, 15-E004TX, 15-E005AX, 15-E005TX, 15-E006TX, 15-E007TX, 15-E008AX, 15-E008TX, 15-E009AX, 15-E009TX, 15-E010AX, 15-E010TX, 15-E011AX, 15-E011TX, 15-E012AX, 15-E012TX, 15-E013AX, 15-E013TX, 15-E014AX, 15-E014TX, 15-E015AX, 15-E016AX, 15-E017AX, 15-E018AX, 15-E019AX, 15-E019TU, 15-E020AX, 15-E020TX, 15-E021AX, 15-E022AX, 15-E022TX, 15-E023TX, 15-E024TX, 15-E025AX, 15-E025TX, 15-E027AX, 15-E028AX, 15-E029AX, 15-E030AX, 15-E030TX, 15-E031AX, 15-E031TX, 15-E032AX, 15-E032TX, 15-E033TX, 15-E035TX, 15-E036TX, 15-E037TX, 15-E045TX, 15-E046TX, 15-E048NR, 15-E049TX, 15-E050TX, 15-E051TX, 15-E051XX, 15-E054TX, 15-E055TX, 15-E056TX, 15-E057TX, 15-E058TX, 15-E059TX, 15-E060TX, 15-E101TX, 15-E102TX, 15-E103TX, 15-N001LA, 15-N002LA, 15-N008AX, 15-N013AX, 15-N014AX, 15-N015AX, 15-N016AX, 15T-E000, 15Z-E000, 15Z-N100, 17-E002XX, 17-E052XX, 17-E054CA, 17Z-E000, 17Z-E100, M4-1001TX, M4-1002TX, M4-1003TX, M4-1004TX, M4-1005TX, M4-1006TX, M4-1007TX, M4-1008TX, M4-1009TX, M4-1010TX, M4-1011TX, M4-1012TX, M4-1013TX, M4-1014TX, M4-1015TX,

Pavilion TouchSmart Series

14Z-N100, 15-N067CA,