

## **SA-45W/19V/2.37A/3\*1**

**Samsung Galaxy View** 18.4 SM-T670 SM-T677 SM-T670NZKAXAR

**Samsung Series 3** NP300U1A NP305U1A NP300u1a-a01us Samsung Series 5 NP530U3C NP540U3C NP530U3B NP530U3BI NP535U3C:

NP530U3B-A01US NP530U3C-A01US NP535U3C-B01US NP540U3C-A01UB NP540U3C-A02UB NP540U3C-A03UB

**Samsung Series 5** Chromebook 500c21 Xe500c21 Xe550c22 Xe550c22-a01us

**Samsung Series 7** Slate XE700T1A

XE700T1A-A01US XE700T1A-A02US XE700T1A-A03US XE700T1A-A05US

**Samsung Series 9** NP900X3E NP900X3B NP900X3C NP900X4B NP900X4D NP900X4C NP900X5N NP900X1A NP900X1B NP900X3A NP900X3D:

NP900X1B-A02 NP900X1B-A02US NP900X3A-A03US NP900X3A-A05US NP900X3A-B01UB NP900X3A-B02US NP900X3A-B06US

NP900X3B-A01US NP900X3C-A01US NP900X3C-A04US NP900X3C-A05US NP900X3D-A01US NP900X3D-A03US NP900X3D-A04US

NP900X3E-A02US NP900X4B-A02US NP900X4C-A01US NP900X4C-A03US NP900X4C-A06US NP900X4C-A07US NP900X4C-K01US

NP900X4D-A02US NP900X4D-A03US NP900X4D-A05US

**Samsung ATIV Book 5** NP540U4E

**Samsung ATIV Book 9** 13.3" 15" NP900X3L NP900X5L NP900X3L-K03US NP900X3L-K04US NP900X3L-K06US NP900X5L-K02US

**Samsung ATIV Book 9 Lite Plus** NP900X3F NP900X3G NP900X3K NP905S3G NP915S3G NP930X5J NP940X3G NP940X3K

NP940X3L NP940X5J:

NP905S3G-K02US NP915S3G-K01US NP915S3G-K02US NP915S3G-K04US NP915S3G-K05US NP940X3G-K01US NP940X3G-K03US

NP940X3G-K04US NP940X3G-K06US NP940X3G-S03US NP940X5J-K01US NP940X5J-K02US NP940X3K-K02US NP-940X3L-K01US

NP540U4E-K01US